

ASPHALT MOUNTING INSTRUCTIONS by FLEXPOST™

Tools Required:

- Marker
- High Speed Power Drill
- 3/4" Masonry Drill Bit
- Wide Flat Head Hammer
- Socket Wrench with 15/16" Drive

Parts Included:

- 1 - Base Plate & Torslon Spring
- 4 - Mungo Plugs
- 4 - Hex Lag Screws
- 4 - Flat Washers

1



- Position base plate and spring in desired mounting location.
- Mark the four base holes to be drilled

2



- Use high speed power drill with 3/4" masonry bit and core drill each hole 6" in depth.

3



- Using wide flat hammer stuff mungo plugs into core drilled holes.

4



- Make sure top of mungo plug is flush with asphalt surface.

5



- Place base over four holes.
- Flat washer and hex screw will be used to secure base.

6



- Using socket wrench with 15/16" drive, thread all four hex lag screws into core drilled holes.

7



- Tighten hex screw until head securely holds base plate in place.

FLEXPOST™ PAT. PEND.

4190 Sunnyside Drive
Holland, MI 49424 USA
Phone (866) 577-2588 or (616) 928-0829
Fax (616) 928-1138